How to Put Together a Preserved Moss Wall Kit

Putting together a preserved moss wall kit is a straightforward project that can transform a bare wall into a living-looking piece of art. The process is more about careful planning and gentle handling than technical skill. If you have ever arranged flowers or assembled a simple picture frame, you already have most of the instincts you need. The key is to work slowly, follow the kit's layout plan, and give yourself enough time to adjust the arrangement before the adhesive sets.

What to Expect Inside the Box

A typical moss wall kit arrives with a frame, a backing board, preserved moss in several shades, preserved foliage accents, and an adhesive. Some kits also include protective gloves and a craft knife. The moss is already treated and dyed, so it requires no water, soil, or sunlight. It will stay soft and green for years if kept out of direct sunlight and away from high humidity.

Before you open anything, clear a large, flat workspace. Lay down newspaper or a drop cloth because the adhesive can be sticky and the moss may shed small particles. Open the kit and check every piece against the included list. If anything is missing or damaged, contact the seller before you start. Once you begin, you cannot return the kit.

Step 1: Prepare the Frame and Backing

Most kits use a wooden frame with a backing board that slides or clips into place. Remove the backing board and set the frame aside. If the backing board has a protective film, peel it off. Some kits come with a pre-applied adhesive layer on the board; others require you to apply the adhesive yourself. Read the instructions carefully to know which type you have.

If you need to apply adhesive, use the one supplied in the kit. Squeeze a thin, even layer onto the board, working in sections so the adhesive does not dry before you place the moss. A small spatula or an old credit card can help spread it smoothly. Wear the protective gloves provided to keep the adhesive off your skin.

Step 2: Lay Out Your Design Before Gluing

This is the most important step. Do not glue anything until you have placed all the moss and foliage on the backing board to see how they fit together. Use the kit's layout plan as a starting point, but feel free to adjust the arrangement to suit your taste. The preserved moss pieces are usually irregular shapes, so you may need to trim them with the craft knife to fit the frame's edges or to create a pleasing gap between colors.

Start with the largest pieces of moss and work down to the smallest. Place the preserved foliage accents last. Step back and look at the board from a few feet away. Does the balance feel right? Is there too much of one color? Do the accents draw the eye where you want them to? Move things around until you are happy. Take a photo with your phone at this stage so you have a reference once the adhesive is applied.

Step 3: Attach the Moss

Once the layout is final, remove the pieces one by one, apply adhesive to the backing board, and press the moss into place. Start from the bottom of the board and work upward so gravity helps keep the moss in position. Press firmly but do not squish the moss. The goal is full contact with the adhesive without flattening the texture.

Work in small sections. If you cover the whole board with adhesive at once, it may dry before you get the moss on. For thicker pieces of moss, you can apply a small amount of adhesive directly to the back of the moss itself. This method gives you more control and prevents glue from seeping out around the edges.

Step 4: Fill Gaps and Trim Edges

After all the main pieces are attached, inspect the board for any bare spots where the backing shows through. Use small scraps of moss to fill these gaps. The craft knife is useful here: trim the scrap to match the shape of the gap, then press it into place with a dab of adhesive.

Check the edges of the board. Moss that extends past the frame line will be crushed when you reinstall the backing. Use the craft knife to trim any overhanging moss flush with the edge of the board. Cut from the back of the moss, not the front, to avoid visible cut lines. This step makes the final piece look clean and professional.

If you are working on this project at Home, the trimming step is where most people notice a difference between a rushed job and a polished one. Take your time and cut carefully. A few extra minutes here will save you from seeing ragged edges every time you walk past the wall.



Step 5: Add the Preserved Foliage Accents

The preserved foliage accents - such as ferns, eucalyptus stems, or small leaves - are the finishing touches that give the moss wall its character. These pieces are usually lighter and more delicate than the moss, so handle them gently. Apply a small dot of adhesive to the back of each accent and press it into place where you decided during the layout step.

Do not overload the board with accents. A few well-placed stems create a natural look; too many make the piece feel busy. Step back again and assess. If an accent feels out of place, remove it before the adhesive sets. Most adhesives in moss kits remain repositionable for a few minutes after application.

Step 6: Let the Adhesive Cure

Once everything is in place, set the board aside in a dry, dust-free area. Let the adhesive cure for the time specified in the kit instructions, usually 12 to 24 hours. Do not rush this. If you install the moss wall before the adhesive is fully set, the moss can shift or fall off over time.


During the curing period, keep the board flat. Do not lean it against a wall or stack anything on top of it. Gravity can pull looser pieces out of position, and pressure can flatten the moss texture.

Step 7: Reinstall the Frame and Hang the Piece

After the adhesive is fully cured, slide the backing board back into the frame. Some frames use small pins or clips to hold the board in place; others rely on a snug fit. If the frame came with hanging hardware, attach it now. Most kits include a sawtooth hanger or a wire hanging system. Use a level to mark the wall where the hanger will go, then drive the nail or screw into a wall stud or use a suitable wall anchor for drywall.

Hang the moss wall and step back to admire your work. The whole process takes a couple of hours spread over two days, with most of that time being the adhesive cure. The result is a custom piece of natural art that requires no maintenance and no watering.


ZITO'S Zen
BOTANICAL ART KIT
CREATE YOUR OWN BOTANICAL ART
ZITO'S Zen
BOTANICAL ART KIT
CREATE • RELAX • ENJOY
BOCA RATON, FLORIDA
CREATING YOUR BOTANICAL ART
ZITO'S ZEN
BOTANICAL ART
Inspiration & Ideas
It's all about how you feel



Whether you place it in a living room, an office, or a bedroom, a preserved moss wall adds a calming, organic element to the space. Many people find that the act of assembling the kit is relaxing in itself - a chance to slow down and work with natural materials. If you are new to this kind of project, start with a small kit to build confidence. Larger kits follow the same steps, just with more pieces and a bigger board.

One thing to keep in mind: preserved moss is not suitable for outdoor use. Rain and direct sunlight will cause the color to fade and the preservation treatment to break down. Keep your moss wall indoors, away from heating vents and windows that get strong afternoon sun. With reasonable care, it will stay vibrant for years.

If you are ever unsure about a step, refer back to the kit's instruction sheet. Every kit is a little different, but the core process - plan, place, adhere, cure, frame - stays the same. Assembling a moss wall kit at Home is a satisfying weekend project that leaves you with a piece of decor that feels both handmade and professional.